



DVD Recorder Guide

1. Before recording, make sure to turn off extra display on Camera LCD.
2. Do not load digital tape to Camera since we only use the lens for signal. DVD recorder does the recording.
3. The default DVD source input is AV-2 (on back, the front is AV-1).

After recording, the DVD disc needs to be closed. Plug the yellow Video signal from “AV splitter” to “connector” to use camera as a monitor, turn camera into play mode.



Close Disc / LiteON LVW-5115 / Easy Guide Button / Disc Tools option / Finalize option / Enter Button



Close Disc / Sony DVD-VCR / System Menu Button / Disc Setting option /

